

## Installation Notes for Wallpaper Finishes

When finishing Stealth Acoustics speakers with wallpaper, it is important to use care when selecting the type of wallpaper being applied. For best results use traditional or vinyl wallpaper up to 1.5mm in thickness. Some types of wallpaper (extra thick, foam, or spongy) can hinder the high frequencies being emitted. This creates a muffled sound from the speaker.

To prep a speaker installation for a wallpaper finish, the wallboard and speakers should be taped, mudded, and sanded according to the instructions for a smooth wall finish. Once the sanding is complete and the wall is free of blemishes; apply a coat of latex primer followed by the wallpaper selection.

As with any wall finish and Stealth Acoustics speakers, it is imperative to never exceed the 1.5mm of material over the face of the speaker. This can result in poor sound quality and is not covered by the manufacturer's defect warranty.

Please contact Stealth Acoustics customer service if you have any further questions regarding wallpaper or other special finishes.